


# PRC-CONTACT-I/O Unit

## Top View – I/O Interface



## **When Connecting for a Relay Interface**

